

LAMP REPLACEMENT:

1. Unplug or switch off the electricity at the mains.
2. Release the front cover screws.
3. Remove and replace lamp. Use a soft cloth; do not touch with bare fingers.
4. Refit front cover, ensure gasket is in position and tighten screws.

REPLACEMENT LAMP TYPE:

Wattage: 1300W
Supply Voltage: 240V
Size: 255mm
Type: R7 IR Ruby Halogen

EVENTUALLY, YOU MAY WANT TO REPLACE THIS LIGHT FITTING:

When your product comes to the end of its life or you choose to update or upgrade it by replacing it, please do not dispose of it with your normal household waste and please recycle where facilities exist. When you need to dispose of this fitting you can check with your retailer or local authority for suitable options. New regulations require the recycling of Waste from Electrical and Electronic Equipment (European "WEEE Directive" effective August 2005—UK WEEE Regulations effective 2nd January 2007). Environment Agency Registered Producer: WEE/GA0248QZ.



SAFETY AND INSTALLATION INSTRUCTIONS



Pack contents:

- 1 x heater c/w 5m mains lead with 3-pin plug
- 1 x mounting bracket
- 1 x bolt
- 1 x locknut



Model:
PAT1300W

1300W WALL MOUNTED PATIO HEATER

These instructions are provided as a guideline to assist you.
PLEASE READ THESE INSTRUCTIONS BEFORE USING YOUR NEW FITTING
PLEASE RETAIN FOR FUTURE REFERENCE

120106-SM



General Information & Cleaning:

READ THIS FIRST:

Check the pack and make sure you have all of the parts listed on the front of this booklet. If not, contact the outlet where you bought this product.

This product contains glass, care must be taken when assembling, fitting or handling to prevent personal injury or damage to the product.

This product must be installed by a competent person in accordance with the current building and IEE wiring regulations.

As the buyer, installer and/or user of this product it is your own responsibility to ensure that this fitting is fit for the purpose for which you have intended it. Eterna Lighting cannot accept any liability for loss, damage or premature failure resulting from inappropriate use.

If in any doubt, consult a qualified electrician.

This product is designed and constructed according to the principles of the appropriate British Standard and is intended for normal domestic service. Using this heater in any other environments may result in a shortened working life.

The heater lamps supplied with this fitting are consumable parts and therefore may be outside of any warranty offered.

Do not use the fitting without the safety shield fitted and replace the safety shield if it is cracked or broken.

When replacing the heater lamp, do not touch with bare fingers, grip the lamp with a tissue or clean soft cloth.

This unit is suitable for indoor and outdoor use.

This product is suitable for installation on surfaces with normal flammability e.g. wood, plasterboard and masonry. It is not suitable for use on highly flammable surfaces (e.g. polystyrene, textiles).

Before making fixing hole(s), check that there are no obstructions hidden beneath the mounting surface such as pipes or cables.

Make sure that the fixings are strong enough to support the considerable weight of the fitting and hold it rigidly.

The heater must be positioned so that there is at least 1.0m between the heater and any other surfaces.

When choosing the location for your new heater, ensure that the fixings will be anchored in a solid surface e.g. concrete, brick or a joist—do not fix directly onto panelling, cladding, plasterboard etc. Always use the supplied baskets where possible.

This product must be connected to earth termination.

WARNING! This product becomes hot!

This product is not intended to be used by children and persons with sensory, physical and/or mental impairments that would prevent them from using it safely.

Small children should be supervised to ensure that they do not play with this appliance.

IMPORTANT— Do not cover or obstruct your patio heater.

Always switch off at the socket and remove the plug before changing the heater lamp.

The plug is fitted with a 13Amp fuse. When replacing, use only a 13Amp fuse approved to BS1362 and carrying the relevant approval mark. Never use the plug with the fuse bypassed or omitted. If the external flexible cable of this heater is damaged it shall be exclusively replaced by a service agent or similar qualified engineer.

If in doubt, consult a qualified electrician

CLEANING:

Disconnect the power and clean the exterior only of this fitting with a moist (not wet) cloth.

Do not use any chemical or abrasive cleaners.

Installation:

INSTALLATION:

Choose the location for your new patio heater giving consideration to the points above.

1. Use the mounting bracket to mark the position of fixing, use a spirit level to ensure it is fixed level.
2. Drill the wall at marked positions & fix the bracket using appropriate fixings (not supplied).
3. Using the bolt and locknut, secure heater/tilting bracket onto the wall bracket previously fixed.
4. Adjust/secure the angle of the heater to provide heat to the desired area by unscrewing/tightening the locknut of the tilting bracket assembly.
5. Ensure that you meet the minimum distance of 1 metre from lighted objects.
6. Ensure that the mains cable does not cause a trip hazard.
7. Insert the plug into a suitable mains supply socket and switch on the power. If the socket or extension lead is situated outdoors it must be the correct IP rated type.

CAUTION:

DO NOT TOUCH THE HEATER OR ADJUST ITS POSITION UNLESS THE POWER IS DISCONNECTED AND IT HAS COOLED DOWN