Installation & Wiring Instructions S-HLP/1 Standalone Emergency LED



PLEASE READ THESE INSTRUCTIONS BEFORE COMMENCING INSTALLATION & LEAVE WITH END USER

Description:

The S-HLP/1 kit is a standalone 3 hour non-maintained emergency driver unit suitable for use with a variety of ceiling mounting LED minispot units. The battery is a 3.2V 3.6 Ah Lithium Iron Phosphate (LiFePO4) that enables the driver to provide a 550mA output to the LED emitter in emergency conditions.

The kit is supplied with a choice of differing LED emitters which offer varying outputs and arcs of illuimance.



Input Voltage	230-240 Volts AC 50/60 Hz					
Input Current & PF	$11mA - \lambda = 0.44$					
Duration	3 hours					
Ambient Temp.	0°C to + 50°C					
Max Case Temperature	70°C					
Max Battery Temperature	55°C					
Mains Input Ferrul Size	0.75mm					
Battery Fuse	Internal					
Battery Discharge Current	600mA					
Discharge Voltage Limit	3.2V					
Ingress Protection	IP20					
Battery Pack	3.2V 3.6Ah LiFePO4					
Charge Current	Dual Rate 0-300mA					
Recharge Period	24 Hours					
Module Size (L x W x H)	165mm x 26.5mm x 21.5mm					
Fixing Centres	157mm					
Battery Size (L x Diameter)	240mm x 24mm					
Module Weight	0.09Kg					
Battery Weight	0.21Kg					
LED Weight	0.06Kg					



Lumen and Optic Angle

S-HLP/1/40/NL S-HLP/1/40/OA S-HLP/1/40/CO S-HLP/1/41 110° Open Area Optic 149 lumen 110° Open Area Optic 161 lumen 125° x 50° Corridor Optic 151 lumen 110° Open Area Optic 176 lumen

Important

It is recommended that the remote kit is installed by a competent person ensuring the installation complies with the necessary standards. Liteplan accept no responsibility for injury, damage or loss, which may arise as a result of incorrect installation, operation or maintenance.

The conversion requires an unswitched supply for charging the battery and a switched supply for maintained operation.

ISOLATE BOTH MAINS SUPPLIES AND DISCONNECT THE BATTERY BEFORE INSTALLATION OR MAINTENANCE.

Installation:

- 1. Cut a 40mm diameter hole in the ceiling tile.
- 2. Connect the LED Bezel to the main assembly via the 4 way connector.
- 3. Connect the 2 core cable as follows Brown Unswitched (Battery Charging) 240V and Blue to Neutral.
- Only connect the battery when the Un-switched supply is fully assured. Even though these units are protected with a Deep Discharge Protection Circuit, the Batteries can be damaged by being left in an uncharged state for prolonged periods. Ensure correct polarity.
- When the supply is present and the battery connected, check that the green LED indicator is illuminated showing that the supply is healthy and the batteries are charging.
- Pass the whole assembly through the 40mm aperture and clip the LED housing into the ceiling.



Installation & Wiring Instructions S-HLP/1 Standalone Emergency LED



PLEASE READ THESE INSTRUCTIONS BEFORE COMMENCING INSTALLATION & LEAVE WITH END USER

Typical Wiring
Diagram

Black - Permanent Live
Blue - Neutral

Emergency Module

4 pole Low Voltage Plug

3 Watt LED Emitter

Testing/Commisioning:

- Ensure the Load is connected.
- Connect the battery.
- Switch on the Unswitched Supply Check the Charge LED illuminates.
- Switch off the Unswitched Supply Check the Charge LED extinguishes and the load LED illuminates at a reduced output.
- Enter the commissioning date on the Battery Pack.
- Switch on the Unswitched Supply

Luminaire Ref/Location			In Case	In Case of difficulty, contact the Installation Engineers:- Tel:							
Full Recharge Time 24 Hours				Duration 3 Hours			Lamp Type - LED				
ROUTINE TEST RECORD											
	Year 1		Year 2		Year 3		Year 4		Year 5		
Monthly Test	Signed	Date	Signed	Date	Signed	Date	Signed	Date	Signed	Date	
Functional											
Functional											
Functional											
Functional											
Functional											
Functional											
Functional											
Functional											
Functional											
Functional											
Functional											
Three Hour											

