

# Meaningful Innovation.

WEEE Number: 80133970

# **INSTRUCTION MANUAL**

LED WATERPROOF BATTEN LIGHT



# **TECHNICAL DATA**

VT-41004	VT-41004S	VT-41005	VT-41005S	VT-41006	VT-41006S		
23071	23072	23075	23076	23079	23080		
20W / 25W / 30W		30W / 40W / 50W		40W / 50W / 60W			
4000K / 5000K / 6500K							
25W &	5000K	40W & 5000K		50W & 5000K			
AC 220-240V, 50Hz							
4200 LM		7000 LM		8400 LM			
1200 x 80 x 72		1500 x 80 x 72		1800 x 80 x 72			
NO	YES	NO	YES	NO	YES		
NO							
120°		120°		120°			
>80		>80		>80			
50,000		50,000		50,000			
PC		PC		PC			
	23071 20W / 25 25W & 420 1200 x NO	23071 23072 20W / 25W / 30W  25W & 5000K  4200 LM 1200 x 80 x 72 NO YES  120° >80 50,000	23071 23072 23075  20W / 25W / 30W 30W / 40  4000K / 500  25W & 5000K 40W &  AC 220-24  4200 LM 7000  1200 × 80 × 72 1500 ×  NO YES NO  120° 12  >80 >8  50,000 50,0	23071 23072 23075 23076  20W / 25W / 30W 30W / 40W / 50W  4000K / 5000K / 6500K  25W & 5000K 40W & 5000K  AC 220-240V, 50Hz  4200 LM 7000 LM  1200 x 80 x 72 1500 x 80 x 72  NO YES NO YES  NO  120° 120°  >80 >80  50,000 50,000	23071 23072 23075 23076 23079  20W / 25W / 30W 30W / 40W / 50W 40W / 50  4000K / 5000K / 6500K  25W & 5000K 40W & 5000K 50W &  AC 220-240V, 50Hz  4200 LM 7000 LM 8400  1200 x 80 x 72 1500 x 80 x 72 1800 x 80  NO YES NO YES NO  120° 120° 120°  >80 >80 >8  50,000 50,000 50,000		

# SAMSUNG LED

Illuminated



IP65
RATING

IK 10 RATING

O5 WARRANTY\*

# SENSOR SPECIFICATION

OPERATING VOLTAGE	MICROWAVE FREQUENCY	MICROWAVE POWER	OPERATING CURRENT	CONTROL MODE	STAND-BY DIMMING LEVEL	STAND BY PERIOD	HOLD TIME	DAYLIGHT THRESHOLD	DETECTION RANGE	DETECTION ANGLE
DC 7.5-12V	5.8 GHz +75Mhz	<0.3mW	<30mA	PWM	0% / 20%	15min/+∞	5s/1min/ 3min/10min	30Lux/ Disable	Ø24M (Max)	Side Wall <150° Ceiling Mount 360°

# REMOTE CONTROL

ONLY BE COMPATIBLE WITH MODELS THAT HAVE SENSOR

BATTERY	DETECTION AREA	STAND-BY DIMMING LEVEL	STAND-BY PERIOD	HOLD TIME	DAYLIGHT THRESHOLD	BRIGHTNESS ADJUST
2xAAA	50% / 100%	0% / 10% /	5min / 15min	30s / 1min	10Lux / 30Lux /	-/+ Button
(Not included)		20% / 30%	/ 30min / + ∞	3min / 10min	50Lux / Disable	on Remote



# MULTI-LANGUAGE MANUAL QR CODE

Please scan the QR code to access the manual in multiple languages.

#### INTRODUCTION & WARRANTY

Thank you for selecting and buying V-TAC product. V-TAC will serve you the best. Please read these instructions carefully before starting the installation and keep this manual handy for future reference. If you have any another query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best. The warranty is valid for 3 years from the date of purchase. The warranty does not apply to damage caused by incorrect installation or abnormal wear and tear. The company gives no warranty against damage to any surface due to incorrect removal and installation of the product. The products are suitable for 10-12 Hours Daily operation. Usage of product for 24 Hours a day would void the warranty. This product is warranted for manufacturing defects only.




This marking indicates that this product should not be disposed of with other household wastes.



Caution, risk of electric shock.

#### WARNING

- 1. Please make sure to turn off the power before starting the installation.
- 2. Installation must be performed by a qualified electrician
- 3. The light source of this luminaire is not replaceable, when the light source reaches its end of life the whole luminaire should be replaced.
- 4. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- 5. Proper grounding should be ensured throughout the installation.
- 6. Please do not install on a surface that is prone to vibrations.
- 7. Contact our customer support team for battery replacement.




#### INSTALLATION PRECAUTIONS


- 1. Microwave sensor can be installed in any lamp except the one with full metal shell.
- 2. The detected surface cannot be shielded by metal objects.
- 3. Make sure the microwave module is completely exposed outside.
- 4. The detection surface of the sensor module shall be installed facing the detection area.
- 5. Should be kept away from the driver to avoid interference generation and lamp flashing.
- 6. Wiring must be strictly in accordance with the wiring diagram to avoid short circuit.


#### **USER NOTES**


- 1. 3M distance is suggested when having a lot sensors in one same room.
- 2. If the sensor is applicated in the room with 5G WiFi router, 3M distance or above is needed.


#### INSTALLATION INSTRUCTION



























# **INSTALLATION INSTRUCTIONS**

- 1. Switch OFF the power before starting the installation.
- 2. Mark and drill the holes on the wall/surface at the correct space for the two surface mounting kits, and fix the kits on the wall/surface.
- 3. Unfasten securing clips.
- 4. Gently open the front cover/diffuser from the backside fitting.
- 5. Click backside fitting to surface mounting kits, Choose suitable Wattage & Colour Temperature by Dip Switch on LED driver.
- 6. Connect supply leads with terminal brown (L) to brown, blue (N) to blue & greenish-yellow (⊕) to greenish-yellow.
- 7. Gently put the front cover/diffuser to the backside fitting.
- 8. Fasten securing clips.
- 9. Switch ON the power to test the light.

# LINKABLE UNITS WIRING DIAGRAM














#### **SENSOR SETTINGS**



**DETECTION AREA** - It can be adjusted by combining DIP switches for specific application [FIG 1]. **HOLD TIME** - Time period during which the light will be ON after the last detection [FIG 2].

**DAYLIGHT THRESHOLD** - Daylight sensor priors motion sensor. Set Threshold for Specific needs. If disabled, only motion sensor will work [FIG 3].

**STAND-BY DIMMING LEVEL** - The dimming level during which the light is ON during the stand-by Period [FIG 4].

**STAND-BY PERIOD** - This is the time period during which the light keeps dimming down after the last detection [FIG 5].

# **AUTOMATICALLY ON/OFF FUNCTION**



With sufficient daylight, even when motion detected, light remains OFF



With insufficient daylight, the sensor turns light ON when motion gets detected.



The sensor turns OFF light automatically after the holdtime when there's no motion detected.

# **DAYLIGHT DISABLE**



The sensor turns light ON when motion gets detected.



The sensor keeps light ON for holdtime period after motion leaves.



The sensor turns OFF light automatically after the holdtime.

When daylight threshold is preset as "disable", the sensor turns light ON when motion gets detected, and OFF after holdtime.

# **CORRIDOR FUNCTION, BI-LEVEL DIMMABLE**



With sufficient daylight, the sensor keeps light OFF even motion gets detected



With insufficient daylight, the sensor turns light ON when motion gets detected.



After there's no motion detected, the sensor keeps light ON 100% for holdtime.




After holdtime, sensor dims light to standby dimming level for standby period.



The sensor turns OFF light automatically after the standby period when there's no motion detected.

# **REMOTE CONTROL (PURCHASE SEPERATELY)**



#### **REMARK**

Indicator light on the remote will blink once every time it successfully delivers command.