

Cleaning:

- > Clean this light fitting only with a soft dry cloth
- > The glass shade may be removed and washed in a mild detergent solution. Make sure the shade is completely dry before putting it back on your light fitting.
- > Do not use any chemical or abrasive cleaners.

Lamp replacement:

- > Switch off the electricity at the mains.
- > Remove the glass shade.
- > Remove and replace lamp.
- > Re-fit glass shade. Ensure that the gasket is in place and take care not to over-tighten.

Replacement lamp type:

	GH111W	GH117W
Wattage:	60 W	100 W
Supply Voltage:	240 V	240 V
Size:	B22 GLS	B22 GLS

Eventually, you may want to replace this light fitting:

When your light fitting comes to the end of its life or you choose to update or upgrade it by replacing it, please do not dispose of it with your normal household waste, please recycle where facilities exist. When you need to dispose of this fitting, check with your retailer or local authority for suitable options. New regulations will encourage the recycling of Waste from Electrical and Electronic Equipment (European "WEEE Directive" effective August 2005).



If you experience problems:

If your light is defective or develops a fault, please return it to the place where you bought it. You can call our Helpline for advice. The Helpline will gladly give advice on any aspect of any Eterna Lighting product but may not be able to give specific instructions regarding individual installations. If in doubt, consult a qualified electrician.

Help line:

Tel: 01933 673 144 Fax: 01933 678 083 Email: sales@eterna-lighting.co.uk



IMPORTANT!

Safety and Installation instructions

Globe ceiling light

Model(s)
GH111W, GH117W

Pack contents:

Globe ceiling fitting gallery	1
Globe ceiling fitting glass shade	1
Silicon heat proof sleeving	2

**PLEASE READ THESE INSTRUCTIONS BEFORE
INSTALLING YOUR NEW FITTING**

PLEASE RETAIN FOR FUTURE REFERENCE

Read this first:

- > If in any doubt, consult a qualified electrician.
- > Switch off the mains before commencing installation and remove the appropriate circuit fuse.
- > Suitable for indoor use only.
- > This product is suitable for installation on surfaces with normal flammability (indicated by the "F" in a triangle) e.g. wood, plasterboard, masonry. It is not suitable for use on highly flammable surfaces (e.g. polystyrene, textiles).
- > Before making fixing hole(s), check that there are no obstructions hidden beneath the mounting surface such as pipes or cables.
- > The chosen location of your new fitting should allow for the product to be securely mounted (e.g. to a ceiling joist) and safely connected to the mains supply (lighting circuit).
- > Do not attach to surfaces which are damp, freshly painted or otherwise electrically conductive (e.g. metallic surfaces).
- > If the location of your new fitting requires the provision of a new electrical supply, the supply must conform with the requirements of the latest edition of the IEE wiring regulations.
- > This product is designed for permanent connection to fixed wiring: this should be either a suitable lighting circuit (protected with a 5 or 6 Amp MCB or fuse) or a fused spur (with a 3 Amp fuse) via a fused connection unit. We recommend that the supply incorporates a switch for ease of operation.
- > Make connections to the electrical supply in accordance with the following code:
 - Live - Brown or Red
 - Neutral - Blue or Black
- > Additional red wires may be present in your ceiling that are connected to the ring live circuit. Do not connect your fitting to these wires. If these wires are not terminated in a ceiling rose, join them together in a separate terminal block (not supplied), ensure that there are no strands of wire protruding from the terminals and wrap well with insulating tape.
- > This fitting is double insulated, do not connect any part to earth.

Installation:

- 1) Remove the glass from the fitting by gently turning anti-clockwise.
- 2) Choose the location for your new light and use the fitting as a template to mark position of the fixing holes.
- 3) Cover the supply cables with the silicon heat proof sleeving supplied.
- 4) Connect the Live and Neutral conductors to the lampholder—see colour code above. Note: the terminals are not designated Live or Neutral and may be connected either way.
- 5) If there is an earth wire present, terminate it in a connector block, wrap well with insulating tape and push it up into the ceiling out of the way of the fitting and the connections.
- 6) Secure the fitting in place using two 1 ½" or 40mm N°8 screws. Ensure that there are no loops of cable trapped behind the fitting and that all excess cable is pushed up into the ceiling.
- 7) Fit a lamp up to the maximum value indicated on the lampholder—see back page for details.
- 8) Re-fit glass shade. Ensure that the gasket is in place and take care not to overtighten.

Safety markings:

